

MB&F

LM1 EVO

LM1 EVO

Functions
Winding / Time setting
Time setting


P.5
P.7
P.9

LM1 EVO




Functions

- 1 Home time zone
- 2 Second time zone
- 3 power reserve indicator



Winding


Your watch is equipped with a manual winding movement. If it has stopped, wind the Home Time crown (A) in position “In” till the maximum power reserve capacity (C). When the power reserve hand is fully pointing to the left of the indicator, the capacity is empty. When it is fully pointing to the right, the capacity is full.



Time Setting

Crown (A) position “Out”: Turn the crown to set the Home Time zone. Slide the crown back against the case when finished.

LM1 EVO



Time Setting

Crown (B) position “Out”: Turn the crown to set the Second Time zone. Slide the crown back against the case when finished.

