

MB&F

LM101 EVO

LM101 EVO

Functions
Winding / Time setting
Time setting

P.5
P.7
P.9

LM101 EVO

Functions


- 1 Hours and minutes
- 2 Power reserve indicator



4

5

LM101 EVO




6

Winding

Your watch is equipped with a manual winding movement. To wind the watch, you must first unscrew the crown (counterclockwise) to release it (A). Once the crown is in position B, wind the crown clockwise until you reach the maximum power reserve capacity (C) as shown in the power reserve indicator (2).

7



Time Setting

First, unscrew the crown (counterclockwise) to release it, then pull the crown to the "out" position, and turn the crown to set the time. Push the crown back against the case and don't forget to screw it in again (clockwise) – this will guarantee water resistance.

www.mbandf.com