

1



1. FUNCTIONS

A – Hours: inner aperture

B – Minutes: outer white track

C – Seconds: central hand

2. WINDING

Your watch is equipped with an automatic movement. If it has stopped, keep the crown pushed in and turn it clockwise approximately 30 times.

When fully wound, the movement offers approximately 55 hours of power reserve.

3. TIME-SETTING

Pull the crown out to its time-setting position. Turn it clockwise or anti-clockwise to set the time forwards or backward, then push it back against the case.

Important: turn the crown slowly and steadily. Do not spin it rapidly or move it repeatedly back and forth, as this may place unnecessary stress on the hour-transition mechanism.

4. HOUR TRANSITION

The hour transition occurs progressively between 57 minutes past and the start of the next hour. During this transition, the hour display may appear between two numerals. This is normal.

The seconds hand operates independently and does not indicate or affect the hour transition.

5. WATER RESISTANCE & CARE

Water-resistant to 3 ATM (30 meters). Suitable for light splashes only. Do not swim, shower or immerse the watch.

Avoid strong impacts, magnetic fields, extreme temperatures and contact with chemicals. Clean with a soft, dry cloth.

6. WARRANTY & SERVICE

Your watch is covered by a two-year electronic warranty, activated automatically upon delivery. No registration is required.

Only M.A.D.Editions is authorized to perform the service.

2



3



Need help? info@madeditions.com