HOROLOGICAL LAB

HMX

HMX

FUNCTIONS 05

OPERATING INSTRUCTIONS WINDING / TIME SETTING 07

HMX



FUNCTIONS

A HOUR

Bi-directional jumping hour

B MINUTE

HMX



OPERATING INSTRUCTIONS

WINDING

Your watch is equipped with an automatic movement.

If it has stopped, wind the crown **(position 1)** a few turns clockwise.

TIME SETTING

Pull the crown "out" **(position 2)** and rotate to set the time.

The time can be set forward or backwards by rotating clockwise or anti-clockwise.

WWW.MBANDF.COM - PRINTED IN SWITZERLAND - JUNE 2015